

DIRECTION TO OPERATORS AT TARAWA TERRACE

- 1. The Booster Pump (D-39) will be started when the Tarawa Terrace reservoir reaches 8'. The Booster Pump will be secured when the reservoir reaches 9'6".
- 2. If the Booster Pump (D-39) has been running and cannot maintain sufficient quantity to Tarawa Terrace, then the Command Duty Officer will be contacted when the Tarawa Terrace reservoir reaches 6'0".
- 3. The person contacted will call you back with approval and instructions on starting TT new well.
- 4. Under no circumstances will TT 26 be operated.
- 5. The Director of Utilities will be notified the following day on actions taken.
- 6. These instructions are to be used during off duty hours.

NOTE: COMMAND DUTY OFFICER PHONE NO: 2523/2528

*L 30 Apr 85*

**CLW**

**0000001193**